

	PTS-T	PTS-N	Emerg	HSM	P/O	RSA	LCA	Look out	IWA	COSS	PC	ES	SWL	PICOP	M/C	M/O	Sig / Tech	Driver	Guard	Shunter	Plat stf	TSR	Ctlr	Pilot/n	DP	PICOS	POCL	Sig'r
WON		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
PON		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
AC		✓																✓	✓	✓			✓	✓	✓	✓	✓	✓
DC		✓																✓	✓	✓			✓	✓	✓	✓	✓	✓
G1		✓																✓	✓	✓			✓	✓	✓	✓	✓	✓
HB1	✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓					✓				✓	✓	
HB2			✓																									
HB3								✓																				
HB4					✓	✓																						
HB5				✓																								
HB6									✓																			
HB7										✓																		
HB8									✓	✓	✓																	
HB9									✓	✓																		
HB9 ERTMS									✓	✓																		
HB10										✓																✓		
HB11														✓														
HB11 ERTMS														✓														
HB12											✓	✓																
HB12 ERTMS											✓	✓																
HB13																										✓		
HB14																											✓	
HB15															✓	✓												
HB15 ERTMS															✓	✓												
HB16	✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓					✓				✓	✓	
HB17	✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓					✓				✓	✓	
HB18							✓																					
HB19																	✓											
HB20													✓															
HB21													✓															
M1																		✓	✓									✓
M2																		✓										✓
M3																		✓						✓				✓
OTM																		✓										✓
P1																		✓						✓				✓
P2																		✓						✓				✓
POSA																		✓	✓	✓	✓			✓				✓
S4																		✓	✓	✓	✓			✓				✓
S5																		✓	✓	✓	✓			✓				✓
S7																		✓	✓	✓	✓			✓				✓
SP																		✓				✓						✓
SS1																		✓	✓	✓	✓			✓				✓
SS2																		✓	✓	✓	✓			✓				✓
T3																		✓										✓
T3 ERTMS																		✓										✓
T10																									✓			✓
TS1																												✓
TS2																												✓
TS3																												✓
TS4																												✓
TS5																												✓
TS7																												✓
TS8																												✓
TS9																												✓
TS10 ERTMS																												✓
TS11																												✓
TW1																		✓	✓	✓								✓
TW5																		✓	✓	✓								✓
TW7																		✓										✓
TW8																		✓										✓
RS516																		✓										✓
RS520																		✓										✓
RS521		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
RS522																		✓										✓
RS523																		✓	✓					✓				✓

These publications are used to update the Rule Book - (WON) weekly and (PON) quarterly

This module is required when working in AC electrified areas

This module is required when working in DC electrified areas

This non-mandatory handbook is for drivers and signallers when working in CSR areas

This non-mandatory handbook is for drivers and signallers when working in IVRS areas

This non-mandatory handbook is for all staff who need to understand the meaning of signals, handsignals, indicators and signs

This non-mandatory handbook is for drivers and signallers who need to understand AWS and TPWS

This non-mandatory handbook is for drivers, signallers and controllers who need to understand the GSMR Radio

These ERTMS documents are for staff who work on ERTMS lines with no line side signals

PTS T = PTS Track worker

PTS N = PTS Non track worker

Emerg = Track workers who use emergency protection equipment

HSM = Handsignaller. This requires PTS T and at least IWA.

P/O = Points operator. This requires PTS T and at least IWA unless person is restricted to working with a RSA

RSA = Route setting agent. This requires PTS T and at least IWA, if working with a P/O must be COSS

LCA = Level crossing attendant. This requires PTS T and at least IWA

Lookout = Lookout and site warden. This requires PTS T

IWA = Individual working alone. This requires PTS T

COSS = Controller of site safety. This requires PTS T

PC = Protection Controller. This requires PTS and COSS T

ES = Engineering Supervisor. This requires PTS T and COSS.

PICOP = Person in charge of possession. This requires PTS T and at least IWA

M/C = Machine controller. This requires PTS T and COSS

M/O = Machine operator. This requires PTS T

Sig/Tech = Signalling Technician. This requires PTS T

TSR = A person who sets up emergency and temporary speed restrictions. This requires PTS T

Ctlr = Operations Controller

Pilot/n = Pilotman. This requires PTS T and at least IWA

DP = Designated Person this requires PTS N

Sig'r = Signaller

PIC- = Person in charge when using a hand trolley

PICOS = Person in charge of sidings possession

POCL = Person in charge of loading and unloading

SWL = Safe work leader